



### **12' and 18' White Titan Assembly Instructions**

Congratulations on your purchase of our 12' or 18' White Titan steel pole.

**For best results, the ground socket should be installed in a permanent concrete bed.**


- Prepare a hole 6" deeper than the length of the ground sleeve.
- Fill bottom with gravel and sand to a depth of 6.
- Install bottom section of the flagpole in the ground sleeve, plumb and tie to stakes set at 3 points around excavation.
- When secure, mix concrete and fill hole to a depth within 6" to 8" from the top of the ground sleeve.
- When concrete has set, fill the excavation to ground level and replace sod.  
*Remove bottom section from ground sleeve for final assembly.*
- Install eyebolt and pulley hole in the top section of the flag pole.
- Install cleat in holes in lower portion of the second section.
- Slip rope through pulley until loose ends are even.
- Assemble the sections.
- Attach the ball ornament to the top.
- Place the flag pole into ground sleeve.
- Tie each flag snap into place.  
*Using a simple overhand knot. Please see diagram.*  
*Always adjust distance between flag snaps to fit the size of the flag being flown.*

**CAUTION: EXTREME CAUTION SHOULD BE EXERCISED WHEN INTALLING FLAG POLES NEAR OVERHEAD POWERLINES OR IN THE VICINITY OF BURRIED CABLES**





### SNAP ILLUSTRATION


ROPE




SNAP COVER



SLIP A LOOP THROUGH  
THE EYE OF THE SNAP



PUT THE LOOP OVER THE SNAP



DRAW TIGHT

